

Detail 21 | Metinno Aluminium Cavity Slider Installation Instructions

Assembly / Installation Instructions

1. Fix head piece to the cavity pocket by screwing the aluminium sections together using the 8g x 30mm pan head screws.
2. Fix the head through the timber rails using the 6g x 20mm pan head screws.
3. Measure the length required for the receiving stile. (The receiving stile is supplied 20mm over length to allow for un-even floor.) Trim the receiving stile to size.
4. Screw the receiving stile into place with the 8g x 30mm pan head screws.
5. The unit can now be stood in place, snapped into the existing head track and fixed to the floor through the metal base.
6. Remove the temporary fabrication screws holding the track and replace them with the 8g x 32mm button head screws, ensuring to fasten to a solid substrate. This will fasten the track, full-height section and head track together.
7. Install the door, then screw the pelmet infill section to the aluminium head section with the 10g x 16mm micro flat head screws, and finally snap the pelmet into place.

